

Furniture options

The standard furniture for a sash window includes locking cam catches, sash lifts for the bottom sash, tilt knobs and either a pole eye or d-handle for the top sash. However, there are many different furniture options available:



Cam catch (brass)



Pole eye (black)



Sash lift (brushed chrome)



Tilt knob (white)



Tilt handle (brass)



Double-stage keep (chrome)



Standard handle (brass)



Rola limit stop (chrome)



Shark fin limit stop (white)



Square handle (brass)



Secured by Design cam catch



Small pole eye (chrome)



Elbow limit stop (white)

Furniture colours

Our standard furniture colours are **white**, **brass**, **chrome**, **brushed chrome** and **black** (see pictures above for examples). Other colours are available on request – please contact us for more information.

For more information on furniture options, please contact us:

Phone: 01234 712657

Fax: 01234 712823

Email: sales@roseview.co.uk